

# Dipole Regulation

Monday Meeting Talk  
Chuck Schmidt  
Nov. 3, 2003

1. Bruker Power Supplies
2. Dipole Magnets –  $45^\circ$  and  $90^\circ$  dipoles
3. NMR
4. Regulation Loop

## **Bruker Power Supplies**

- **25 V – (8 to 15 V operation)**
- **5 A – (3.1 to 4.0 A operation)**
- **100 ppm stability (10 ppm for 1 min) – Operation at least this good**
- **16 bit DAC/ADC (15 ppm) resolution)**
- **Least Significant Bit ~ 76 microamps**
- **Resolution:  $76 \mu\text{A} / 3.2 \text{ A} = 2.4 \text{ e-5}$**

## Dipole Magnets

- “Estimations on stability of WB beam line elements' currents”

A.Burov, S.Seletsky, A. Shemyakin 15-Oct-03

Based on max angle in the cooling section of 0.01 mrad.

Dipoles:  $B \cdot dl \sim 7.0e-5$  stability

- Steel: Thermal expansion  $\sim 1.1e-5 / ^\circ C$

- Operating values:

Energy (MeV)	45 <sup>o</sup> dipoles		90 <sup>o</sup> dipoles	
	Field (G)	Current (A)	Field (G)	Current (A)
3.50	262	3.2	395	3.1
4.35	320	4.0	481	3.9

- Field stability  $< \sim 300G \times 7e-5 = 21e-3G$  or 20 mG

- Least Significant Bit  $\sim 76 \mu A$   $\sim 6 mG$

- 45<sup>o</sup> dipoles – 90<sup>o</sup> bends:

Homogeneous field


NMR probe at inside radius of beam chamber  
on midplane

Resulting field errors for at NMR corrected  
with figure-8 coils

- 90<sup>o</sup> dipoles – 180<sup>o</sup> bend:


Gradient field –  $n = 0.5 \pm 0.05$

Special correction at pole edge for NMR



## NMR Gaussmeter

- Range: 250 to 600 G
- 12 channels
- Water sample measuring the “spin-echo” signal



$$B = \gamma f$$

Gyromagnetic ratio,  $\gamma = 42.57639 \text{ MHz/T}$   
 $300\text{G} = 1.27729 \text{ MHz}$

- Regulation Loop Sensitivity:
  - With field gradient less than  $0.2\text{G/cm}$   
 $< 10 \text{ ppm}$
  - With field gradient  $0.4\text{G/cm}$   
 $\sim 30 \text{ ppm}$
- Signal-to noise  $\sim B^2$ 
  - $260\text{G}$  marginal
  - $320\text{G}$  significantly better

## Regulation Loop

Closes loop between NMR readings and Power Supply setting through software:

- Average 10 readings of each NMR channel (dipole reading). Maintain a running average of the last 10 field readings.
- If any reading exceeds 50 mG consider bad and ignore in average.
- If average exceeds  $\pm 10$  mG, increase or decrease setting of dipole PS by 1 LSB ( $\sim 76$  uA  $\sim 6$  mG)

Console operations:

To use the regulating loop

### 1. Set the PS to desired value

• E:DYS01I	BRUKER Bend PS 01	3.28	3.28	Amp	*
------------	-------------------	------	------	-----	---

### 2. Enter expected field for NMR D/A and start NMR search by clicking first star and on.

• E:DYS01G	Pelletron NMR PS 01	262.46	262.6238	Gaus	***
------------	---------------------	--------	----------	------	-----

### 3. NMR will search (?) in sequence with other channel tasks and give field (A/D) if found. Field must be within $\sim 10$ G of setting.

### 3. Adjust current of PS or NMR D/A setting until field and setting agree (within 10mG)

• E:DYR01I	BRUKER Bend PS 05	3.12978	3.12978	Amp	*
------------	-------------------	---------	---------	-----	---

• E:DYR01G	Pelletron NMR PS 05	395.03	395.0364	Gaus	****
------------	---------------------	--------	----------	------	------

**4. Click last star and PLUS to start regulation.**

**5. If all is well both stars will remain green. (If red, regulation is off.)**

**6. After 10-cycle average, if NMR setting and reading differ by  $\pm 10\text{mG}$ , PS will be corrected**

**7. If too large an error occurs ( $\pm 50\text{ mG}$  or more) the regulation may drop out and need restarting.**

- **To turn off regulation, interrupt last star and MINUS**

- **Small changes  $< 50\text{mG}$  can be made by changing the NMR D/A setting while regulating.**

- **Large changes made through the PS may trip off the NMR reading and will require resetting the NMR.**

- **Dipole-NMR regulation should maintain the NMR field reading (A/D) to within  $\pm 10\text{ mGauss}$  of the desired field setting (D/A), ie.  $\pm 3.5 \times 10^{-5}$  or  $7.0 \times 10^{-5}$ .**